

Fl. 4, No. 135, Lane 235, Baoqiao Rd., Xindian Dist., New Taipei City 23145, Taiwan, R.O.C.

Tel: +886-2-8919-1230 Fax: +886-2-8919-1231 www.moxa.com

IEC 60870-5-101 Slave PICS for MGate 5114

Interoperability

This companion standard presents sets of parameters and alternatives from which subsets must be selected to implement particular telecontrol systems. Certain parameter values, such as the choice of "structured" or "unstructured" fields of the INFORMATION OBJECT ADDRESS of ASDUs represent mutually exclusive alternatives. This means that only one value of the defined parameters is admitted per system. Other parameters, such as the listed set of different process information in command and in monitor direction allow the specification of the complete set or subsets, as appropriate for given applications. This clause summarizes the parameters of the previous clauses to facilitate a suitable selection for a specific application. If a system is composed of equipment stemming from different manufacturers, it is necessary that all partners agree on the selected parameters.

The interoperability list is defined as in IEC 60870-5-101 and extended with parameters used in this standard. The text descriptions of parameters which are not applicable to this companion standard are strike-through (corresponding check box is marked black).

NOTE In addition, the full specification of a system may require individual selection of certain parameters for certain parts of the system, such as the individual selection of scaling factors for individually addressable measured values.

The	selected parameters should	be mar	ked in the white boxes as follows:
	Function or ASDU is not us	ed	
X	Function or ASDU is used a	as stand	dardized (default)
R	Function or ASDU is used i	n rever	se mode
В	Function or ASDU is used i	n stand	ard and reverse mode
The	possible selection (blank, X,	R, or B	s) is specified for each specific clause or parameter.
A bla	ck check box indicates that	the opti	on cannot be selected in this companion standard.
1.1	System or device (system-specific parameter the following with "X")	, indica	te definition of a system or a device by marking one of
	System definition		
	Controlling station definition	n (Mast	er)
X	Controlled station definition	(Slave))
1.2	Network configuration (network-specific paramete	r, all co	onfigurations that are used are to be marked "X")
X	Point-to-point	X	Multipoint-partyline
X	Multiple point-to-point		Multipoint-star

1.3 Physical layer

(network-specific parameter, all interfaces and data rates that are used are to be marked "X")



Fl. 4, No. 135, Lane 235, Baoqiao Rd., Xindian Dist., New Taipei City 23145, Taiwan, R.O.C.

Tel: +886-2-8919-1230 Fax: +886-2-8919-1231 www.moxa.com

<u>Transmission speed (control direction)</u>

Unbalanced interchange Circuit V.24/V.28 Standard	Unbalanced Circuit V.24/ Recommend	V.28	Circ	nced inte uit X.24/>		ge				
X 100 bit/s	X 2 400	bit/s	X	2 400	bit/s		56 000	bit/s		
X 200 bit/s	X 4 800	bit/s	X	4 800	bit/s		64 000	bit/s		
X 300 bit/s	X 9 600	bit/s	X	9 600	bit/s					
X 600 bit/s			X	19 200	bit/s					
X 1 200 bit/s			X	38 400	bit/s					
Transmission speed (mo	onitor direction)	<u>L</u>								
Unbalanced interchange Circuit V.24/V.28 Standard	Unbalanced Circuit V.24/ Recommend	V.28	Circ	nced inte uit X.24/)		ge				
X 100 bit/s	X 2 400	bit/s	X	2 400	bit/s		56 000	bit/s		
X 200 bit/s	X 4 800	bit/s	X	4 800	bit/s		64 000	bit/s		
X 300 bit/s	X 9 600	bit/s	X	9 600	bit/s					
X 600 bit/s			X	19 200	bit/s					
X 1 200 bit/s			X	38 400	bit/s					
parameter, all opt length. If a non-sta	1.4 Link layer (network-specific Time during which repetitions are permitted (Trp) or number of repetitions parameter, all options that are used are to be marked "X". Specify the maximum frame length. If a non-standard assignment of class 2 messages is implemented for unbalanced transmission, indicate the Type ID and COT of all messages assigned to class 2.)									
this companion standard	-							,		
Link transmission		Addres	ss field of th	<u>e link</u>						
X Balanced transmiss	sion	X	Not present	(balanc	ed trar	nsmissi	on only)			
X Unbalanced transm	nission	X	One octet							
Frame length		X	Two octets Structured							
252 Maximum leng (control directi			Unstructure	ed						
252 Maximum leng										

Time during which repetitions are permitted (Trp) or number of repetitions



Fl. 4, No. 135, Lane 235, Baoqiao Rd., Xindian Dist., New Taipei City 23145, Taiwan, R.O.C.

Tel: +886-2-8919-1230 Fax: +886-2-8919-1231 www.moxa.com

When using an unbalanced link layer, the following ASDU types are returned in class 2 messages (low priority) with the indicated causes of transmission:

X	The standard assignment	of ASDUs to	class 2 messages	s is used as follows:
	Type identification	Cause of	f transmission	
	9, 11, 13, 21		<1>	_
	A special assignment of A Type identification	_	ss 2 messages is of transmission	used as follows:
				_
Note: availa		controlled static	on may respond with c	lass 1 data when there is no class 2 data
1.5	Application layer			
Tran	smission mode for appl	ication data		
	e 1 (Least significant octe is companion standard.	t first), as de	fined in 4.10 of IE	C 60870-5-4, is used exclusively
	mon address of ASDU em-specific parameter, al	l configuration	ns that are used a	re to be marked " X ")
X	One octet	X	Two octets	
	rmation object address em-specific parameter, al	l configuration	ns that are used a	re to be marked " X ")
X	One octet		Structured	
X	Two octets		Unstructured	
X	Three octets			
	se of transmission em-specific parameter, al	I configuration	ns that are used a	re to be marked " X ")
X	One octet	X		originator address). ss is set to zero if not used



Fl. 4, No. 135, Lane 235, Baoqiao Rd., Xindian Dist.,

New Taipei City 23145, Taiwan, R.O.C.

Tel: +886-2-8919-1230 Fax: +886-2-8919-1231 www.moxa.com

Selection of standard ASDUs

Process information in monitor direction

(station-specific parameter, mark each Type ID "X" if it is only used in the standard direction, "R" if only used in the reverse direction, and "B" if used in both directions).

_			
X	<1>	:= Single-point information	M_SP_NA_1
X	<2>	:= Single-point information with time tag	M_SP_TA_1
X	<3>	:= Double-point information	M_DP_NA_1
X	<4>	:= Double-point information with time tag	M_DP_TA_1
X	<5>	:= Step position information	M_ST_NA_1
X	<6>	:= Step position information with time tag	M_ST_TA_1
X	<7>	:= Bitstring of 32 bit	M_BO_NA_1
X	<8>	:= Bitstring of 32 bit with time tag	M_BO_TA_1
X	<9>	:= Measured value, normalized value	M_ME_NA_1
X	<10> :=	Measured value, normalized value with time tag	M_ME_TA_1
X	<11> :=	Measured value, scaled value	M_ME_NB_1
X	<12> :=	Measured value, scaled value with time tag	M_ME_TB_1
X	<13> :=	Measured value, short floating point value	M_ME_NC_1
X	<14>:=	Measured value, short floating point value with time tag	M_ME_TC_1
X	<15> :=	Integrated totals	M_IT_NA_1
X	<16> :=	Integrated totals with time tag	M_IT_TA_1
	<17> :=	Event of protection equipment with time tag	M_EP_TA_1
	<18> :=	Packed start events of protection equipment with time tag	M_EP_TB_1
	<19> :=	Packed output circuit information of protection equipment with time tag	M_EP_TC_1
	<20> :=	Packed single-point information with status change detection	M_SP_NA_1
	<21>:=	Measured value, normalized value without quality descriptor	M_ME_ND_1
_			
X	<30> :=	Single-point information with time tag CP56Time2a	M_SP_TB_1
X	<31> :=	Double-point information with time tag CP56Time2a	M_DP_TB_1
X	<32> :=	Step position information with time tag CP56Time2a	M_ST_TB_1
X	<33> :=	Bitstring of 32 bit with time tag CP56Time2a	M_BO_TB_1
X	<34> :=	Measured value, normalized value with time tag CP56Time2a	M_ME_TD_1
X	<35> :=	Measured value, scaled value with time tag CP56Time2a	M_ME_TE_1
X	<36> :=	Measured value, short floating point value with time tag CP56Time2a	M_ME_TF_1
X	<37> :=	Integrated totals with time tag CP56Time2a	M_IT_TB_1
	<38> :=	Event of protection equipment with time tag CP56Time2a	M_EP_TD_1
	<39> :=	Packed start events of protection equipment with time tag CP56Time2a	M_EP_TE_1
	<40> :=	Packed output circuit information of protection equipment with time tag CP56Time2a	M_EP_TF_1

Either ASDUs of the set <2>, <4>, <6>, <8>, <10>, <12>, <14>, <16>, <17>, <18>, <19> or of the set <30 - 40> are used.



Fl. 4, No. 135, Lane 235, Baoqiao Rd., Xindian Dist., New Taipei City 23145, Taiwan, R.O.C.

Tel: +886-2-8919-1230 Fax: +886-2-8919-1231 www.moxa.com

Process information in control direction

(station-specific parameter, mark each Type ID "X" if it is only used in the standard direction, "R" if only used in the reverse direction, and "B" if used in both directions).

	X	<45> :=	Single command	C_SC_NA_1
	X	<46> :=	Double command	C_DC_NA_1
	X	<47> :=	Regulating step command	C_RC_NA_1
	X	<48> :=	Set point command, normalized value	C_SE_NA_1
	X	<49> :=	Set point command, scaled value	C_SE_NB_1
	X	<50> :=	Set point command, short floating point value	C_SE_NC_1
ſ	Х	<51> :=	Bitstring of 32 bit	C_BO_NA_1

System information in monitor direction

(station-specific parameter, mark with an "X" if it is only used in the standard direction, "R" if only used in the reverse direction, and "B" if used in both directions).

[3.6	1	
X	<70>:= End of initialization	M_EI_NA_1

System information in control direction

(station-specific parameter, mark each Type ID "X" if it is only used in the standard direction, "R" if only used in the reverse direction, and "B" if used in both directions).

X	<pre></pre> <pre>< 100>:= Interrogation command</pre>	C_IC_NA_1
X	<101>:= Counter interrogation command	C_CI_NA_1
X	<102>:= Read command	C_RD_NA_1
X	<103>:= Clock synchronization command (option see 7.6)	C_CS_NA_1
	<104>:= Test command	C_TS_NA_1
	<105>:= Reset process command	C_RP_NA_1
	<106>:= Delay acquisition command	C_CD_NA_1



Fl. 4, No. 135, Lane 235, Baoqiao Rd., Xindian Dist.,

New Taipei City 23145, Taiwan, R.O.C.

Tel: +886-2-8919-1230 Fax: +886-2-8919-1231 www.moxa.com

F_SG_NA_1

F_DR_TA_1

Parameter in control direction

(station-specific parameter, mark each Type ID "X" if it is only used in the standard direction, "R" if only used in the reverse direction, and "B" if used in both directions).

	<110>:= Parameter of measured value, normalized value	P_ME_NA_1
	<111>:= Parameter of measured value, scaled value	P_ME_NB_1
	<112>:= Parameter of measured value, short floating point value	P_ME_NC_1
	<113>:= Parameter activation	P_AC_NA_1
(st	e transfer ation-specific parameter, mark each Type ID " X " if it is only used in the sta " if only used in the reverse direction, and " B " if used in both directions).	andard direction,
	<pre><120>:= File ready</pre>	F_FR_NA_1
	<121>:= Section ready	F_SR_NA_1
	<122>:= Call directory, select file, call file, call section	F_SC_NA_1
	<123>:= Last section, last segment	F_LS_NA_1
	<pre><124>:= Ack file, ack section</pre>	F_AF_NA_1

Type identifier and cause of transmission assignments

<126>:= Directory {blank or X, only available in monitor (standard) direction}

(station-specific parameters)

<125>:= Segment

Shaded boxes are not defined in this companion standard and shall not be used.

Black boxes: option not permitted in this companion standard

Blank: functions or ASDU not used.

Mark Type Identification/Cause of transmission combinations:

- "X" if only used in the standard direction;
- "R" if only used in the reverse direction;
- "B" if used in both directions.

Type identi	ification	Cause of transmission																		
		1	2	3	4	5	6	7	8	9	10	11	12	13	20	37	44	45	46	47
															to	to				
															36	41				
<1>	M_SP_NA_1			Х		Х						Χ			Χ					
<2>	M_SP_TA_1			Х		Х						Χ								
<3>	M_DP_NA_1			Х		Х						Х			Х					
<4>	M_DP_TA_1			Х		Х						Х								
<5>	M_ST_NA_1			Х		Х						Х			Х					
<6>	M_ST_TA_1			Х		Х						Х								
<7>	M_BO_NA_1			Х		Х									Х					
<8>	M_BO_TA_1			Х		Х														
<9>	M_ME_NA_1	Х		Х		Х									Х					
<10>	M_ME_TA_1			Х		Х														
<11>	M_ME_NB_1	Х		Χ		Х									Χ					
<12>	M_ME_TB_1			Χ		Х														



Fl. 4, No. 135, Lane 235, Baoqiao Rd., Xindian Dist., New Taipei City 23145, Taiwan, R.O.C.

Tel: +886-2-8919-1230 Fax: +886-2-8919-1231 www.moxa.com

Type identific		Cause of transmission																		
		1	2	3	4	5	6	7	8	9	1 0	1	1 2	1 3	20 to 36	37 to 41	44	45	46	47
<13>	M_ME_NC_1	Х		Х		Х									Х	7.				
<14>	M_ME_TC_1			Х		Х														
<15>	M_IT_NA_1			Х												Х				
<16>	M_IT_TA_1			Х												Х				
<17>	M_EP_TA_1																			
<18>	M_EP_TB_1																			
<19>	M_EP_TC_1																			
<20>	M_PS_NA_1																			
<21>	M_ME_ND_1																			
<30>	M_SP_TB_1			Х		Х						Х								
<31>	M_DP_TB_1			Х		Х						Х								
<32>	M_ST_TB_1			Х		Х						Х								
<33>	M_BO_TB_1			Х		Х														
<34>	M_ME_TD_1			Х		Х														
<35>	M_ME_TE_1			Х		Х														
<36>	M_ME_TF_1			Х		Х														
<37>	M_IT_TB_1			Х												Х				
<38>	M_EP_TD_1																			
<39>	M_EP_TE_1																			
<40>	M_EP_TF_1																			
<45>	C_SC_NA_1						Х	Х	Х	Х	Х						Х	Х	Х	
<46>	C_DC_NA_1						Х	Х	Х	Х	Х						Х	Х	Х	
<47>	C_RC_NA_1						Х	Х	Х	Х	Х						Х	Х	Х	
<48>	C_SE_NA_1						Х	Х	Х	Х	Х						Х	Х	Х	
<49>	C_SE_NB_1						Х	Х	Х	Х	Х						Х	Х	Х	
<50>	C_SE_NC_1						Х	Х	Х	Х	Х						Х	Х	Х	
<51>	C_BO_NA_1						Х	Х	Х	Х	1						Х	Х	Х	
<70>	M_EI_NA_1*																			
<100>	C_IC_NA_1						Х	Х	Х	Х	Х						Х	Х	Х	
<101>	C_CI_NA_1						Х	Х			Х						Х	Х	Х	
<102>	C_RD_NA_1					Х											Х	Х	Х	1
<103>	C_CS_NA_1						Х	Х									X	X	X	
<104>	C_TS_NA_1						<u> </u>													
<105>	C_RP_NA_1																			
<106>	C_CD_NA_1																			
<100>	C_CB_NA_1 C_TS_TA_1																			\vdash
<110>	P_ME_NA_1																			\vdash
<111>	P_ME_NB_1																			┢
<112>	P_ME_NC_1																			┢
<113>	P_ME_NC_1 P_AC_NA_1																			┢
<120>	F_RC_NA_1 F_FR_NA_1																			┢
<120>	F_FR_NA_1 F_SR_NA_1																			┢
<121>	F_SC_NA_1																			╁
																				╁
<123> <124>	F_LS_NA_1																			⊨
	F_AF_NA_1																			⊨
<125> <126>	F_SG_NA_1 F_DR_TA_1*																			H
	1 _DV_14_1																			Ш

1.6 Basic application functions

Stati	on initialization
(stati	on-specific parameter, mark "X" if function is used)
	Remote initialization



Fl. 4, No. 135, Lane 235, Baoqiao Rd., Xindian Dist., New Taipei City 23145, Taiwan, R.O.C.

Tel: +886-2-8919-1230 Fax: +886-2-8919-1231 www.moxa.com

Cyclic data transmission

(station-specific parameter, mark "X" if function is only used in the standard direction, "R" if only used in the reverse direction, and "B" if used in both directions)

 \mathbf{X} Cyclic data transmission Read procedure (station-specific parameter, mark "X" if function is only used in the standard direction, "R" if

only used in the reverse direction, and "B" if used in both directions)

Read procedure

Spontaneous transmission

(station-specific parameter, mark "X" if function is only used in the standard direction, "R" if only used in the reverse direction, and "B" if used in both directions)

Spontaneous transmission

Double transmission of information objects with cause of transmission spontaneous (station-specific parameter, mark each information type "X" where both a Type ID without time and corresponding Type ID with time are issued in response to a single spontaneous change of a monitored object)

The following type identifications may be transmitted in succession caused by a single status change of an information object. The particular information object addresses for which double transmission is enabled are defined in a project-specific list.

Single-point information M_SP_NA_1, M_SP_TA_1, M_SP_TB_1 and M_PS_NA_1
Double-point information M_DP_NA_1, M_DP_TA_1 and M_DP_TB_1
Step position information M_ST_NA_1, M_ST_TA_1 and M_ST_TB_1
Bitstring of 32 bit M_BO_NA_1, M_BO_TA_1 and M_BO_TB_1 (if defined for a specific project)
Measured value, normalized value M_ME_NA_1, M_ME_TA_1, M_ME_ND_1 and M_ME_TD_1
Measured value, scaled value M_ME_NB_1, M_ME_TB_1 and M_ME_TE_1
Measured value, short floating point number M_ME_NC_1, M_ME_TC_1 and M_ME_TF_1



Fl. 4, No. 135, Lane 235, Baoqiao Rd., Xindian Dist., New Taipei City 23145, Taiwan, R.O.C.

Tel: +886-2-8919-1230 Fax: +886-2-8919-1231 www.moxa.com

Station interrogation

(station-specific parameter, mark "X" if function is only used in the standard direction, "R" if only used in the reverse direction, and "B" if used in both directions).

X	global					
X	group 1	X g	roup 7		X group 13	
X	group 2	X g	roup 8		X group 14	
X	group 3	X g	roup 9		X group 15	
X	group 4	X g	roup 10	0	x group 16	
X	group 5	X g	roup 1	1	Information object addresses assigned to each	
X	group 6	X g	roup 12	2	group must be shown in a separate table.	
Clock synchronization (station-specific parameter, mark "X" if function is only used in the standard direction, "R" if only used in the reverse direction, and "B" if used in both directions).						
X	Clock synchronization					
	Day of week used					
	RES1, GEN (time tag substituted/ not substituted) used					
	SU-bit (summertime) used					
optional, see 7.6						
Command transmission (object-specific parameter, mark "X" if function is only used in the standard direction, "R" if only used in the reverse direction, and "B" if used in both directions).						
X	Direct command	transm	nission			
X	Direct set point command transmission					
X	Select and execute command					
X	Select and execute set point command					
X	C_SE ACTTERM used					
X	No additional def	inition				
	Short-pulse duration (duration determined by a system parameter in the outstation)					
	Long-pulse duration (duration determined by a system parameter in the outstation)					
X	Persistent output					



www.moxa.com

Fl. 4, No. 135, Lane 235, Baoqiao Rd., Xindian Dist., New Taipei City 23145, Taiwan, R.O.C.

Tel: +886-2-8919-1230 Fax: +886-2-8919-1231

Transmission of integrated totals

(station- or object-specific parameter, mark "X" if function is only used in the standard direction, "R" if only used in the reverse direction, and "B" if used in both directions).

	Mode A: Local freeze with spontaneous transmission
	Mode B: Local freeze with counter interrogation
	Mode C: Freeze and transmit by counter-interrogation commands
	Mode D: Freeze by counter-interrogation command, frozen values reported
☞	Country road
X	Counter read
\sqcup	Counter freeze without reset
Ш	Counter freeze with reset
	Counter reset
X	General request counter
X	Request counter group 1
X	Request counter group 2
$\overline{\mathbf{x}}$	Request counter group 3
X	Request counter group 4
(obje	ameter loading ect-specific parameter, mark "X" if function is only used in the standard direction, "R" if only if in the reverse direction, and "B" if used in both directions).
	Threshold value
	Smoothing factor
	Low limit for transmission of measured values
	High limit for transmission of measured values
(obje	ameter activation ect-specific parameter, mark "X" if function is only used in the standard direction, "R" if only in the reverse direction, and "B" if used in both directions).
	Act/deact of persistent cyclic or periodic transmission of the addressed object
(stat	t procedure ion-specific parameter, mark "X" if function is only used in the standard direction, "R" if used in the reverse direction, and "B" if used in both directions).
\Box	Test procedure



Acquisition of transmission delay

Moxa Inc.

Fl. 4, No. 135, Lane 235, Baoqiao Rd., Xindian Dist., New Taipei City 23145, Taiwan, R.O.C.

Tel: +886-2-8919-1230 Fax: +886-2-8919-1231 www.moxa.com

File transfer (station-specific parameter, mark "X" if function is used). File transfer in monitor direction Transparent file Transmission of disturbance data of protection equipment Transmission of sequences of events Transmission of sequences of recorded analogue values File transfer in control direction Transparent file **Background scan** (station-specific parameter, mark "X" if function is only used in the standard direction, "R" if only used in the reverse direction, and "B" if used in both directions). Background scan Acquisition of transmission delay (station-specific parameter, mark "X" if function is only used in the standard direction, "R" if only used in the reverse direction, and "B" if used in both directions).